

Install update

To update a LGZ USB Recorder, follow these instructions:

- Copy the file you've received that is containing the update (it ends in ".tar.gz") on to an empty USB stick.
- Right-click the file on the USB stick and uncompress it on that same USB stick. New files should then appear on the USB stick.
- Ensure that your USB Recorder is ON and plug in the USB stick containing the update files.
- Wait between 20 seconds and 2 minutes.
- The LGZ USB Recorder should shut itself down.
- Unplug the USB stick containing the update files
- Start your USB Recorder and control inside the INFO menu that the version has been updated.

Try another USB stick or make sure the files were properly uncompressed to the USB stick if it doesn't work.

Access web interface

If connecting through a laptop/computer that is connected directly to the USB Recorder with an ethernet cable:

- Make sure the unit is in Fixed IP mode (default). It should have (also factory default) an IP of 192.168.0.100 (it can be read in the INFO menu). Make sure your computer/laptop settings are set properly (local network) and type in the Units IP address in your web browser (default is as said 192.168.0.100). You should then be able to access and control the unit.

If connecting to a unit that is in a DHCP network:

- Set your unit to DHCP mode.
- Restart it after it is connected to the network
- Read the IP it was assigned by the local router in the INFO menu window on the unit.
- Type the IP address in a browser on a computer connected to the local network

Remember that after DHCP mode is set the unit must be restarted in the network to properly receive and present its new IP address.

Don't hesitate to contact us at: info@lgztech.com

LGZ Team